

PRODUCT DATA PACK (PDP)	PDP REF: PDP-B3015-ANIGENE V01	
NAME: ANIGENE Professional Surface Disinfectant Spray CODE: B3015		

DOCUMENT ISSUE			
ROLE	NAME	JOB TITLE	SIGN & DATE
AUTHOR	Matthew Hunt	Microbiologist	<i>Matthew Hunt</i> Matthew Hunt (Oct 1, 2024 10:15 GMT+1)
REVIEWER	Dr Chris Plummer	Head of Technology	<i>C. Plummer</i> C. Plummer (Oct 1, 2024 11:52 GMT+1)
QUALITY APPROVER	Megan Bowles	Quality Specialist	<i>Megan Bowles</i> Megan Bowles (Oct 1, 2024 11:54 GMT+1)
ISSUED BY	Megan Bowles	Quality Specialist	<i>Megan Bowles</i> Megan Bowles (Oct 1, 2024 11:54 GMT+1)
ISSUE DATE	01 OCT 2024	REVIEW DATE	01 OCT 2026

PRODUCT INFORMATION	
PRODUCT NAME	ANIGENE Professional Surface Disinfectant Spray
PRODUCT CODE	B3015
FORMULATION VARIANTS	B3015 – Un-fragranced
SDS REFERENCE	SDS-B3015
NOTE: ACTIVE INGREDIENTS AND SAFETY INFORMATION DETAILED IN SDS	
DIRECTIONS FOR USE	For professional use only Refer to the safety data sheet prior to use For use on hard, non-porous surfaces Ready-to-use formulation Remove excess dirt and soiling prior to disinfection Direct spray nozzle to the surface, hold the trigger and apply product liberally to the surface Leave for the required contact time before wiping away any excess solution or leave to air dry Product can be used around or near animals for routine cleaning of animal housing and equipment. Exotic animals, amphibians and reptiles should be removed prior to use People need not be excluded from the areas during use Always rinse food / water bowls and toys with water after disinfection
APPLICATION AREAS	PT3 – Veterinary Hygiene
STORAGE CONDITIONS	Keep out of reach of children. If medical advice is needed, have product container or label at hand. Avoid release to the environment. Dispose of contents/container in accordance with national regulations. Incompatibility with other materials: Oxidising Substances, Anionics, Hypochlorite, Aldehydes.

PRODUCT DATA PACK (PDP)	PDP REF: PDP-B3015-ANIGENE V01	
NAME: ANIGENE Professional Surface Disinfectant Spray CODE: B3015		

SHELF-LIFE	2-Years Established following criteria for accelerated storage test in section 3.4.1.1 of ECHA guidance on the BPR: Volume 1. Part A. Chapter III: Required for Biocidal Products. Version 1.1 November 2014
-------------------	---

PRODUCT SPECIFICATION	
APPEARANCE	Clear liquid free of suspended matter
COLOUR	Colourless to pale yellow
ODOUR	Characteristic
pH	10.0 – 11.0
SPECIFIC GRAVITY	0.99-1.02 g/cm ³ at 20 °C
VISCOSITY	N/A

BACTERICIDAL EFFICACY					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN1656	<i>Enterococcus hirae</i>	1 min, Low soil, 10°C	>5 log reduction	TR-930	N/A
EN14349	<i>Enterococcus hirae</i>	1 min, Low soil, 10°C	>4 log reduction	TR-934	N/A
EN1656	<i>Pseudomonas aeruginosa</i>	1 min, Low soil, 10°C	>5 log reduction	TR-930	N/A
EN14349	<i>Pseudomonas aeruginosa</i>	1 min, Low soil, 10°C	>4 log reduction	TR-934	N/A
EN1656	<i>Staphylococcus aureus</i>	1 min, Low soil, 10°C	>5 log reduction	TR-930	N/A
EN14349	<i>Staphylococcus aureus</i>	1 min, Low soil, 10°C	>4 log reduction	TR-934	N/A
EN1656	<i>Proteus hauseri</i>	1 min, Low soil, 10°C	>5 log reduction	TR-930	N/A
EN14349	<i>Proteus hauseri</i>	1 min, Low soil, 10°C	>4 log reduction	TR-934	N/A
EN1656	<i>Escherichia coli</i>	1 min, Low soil, 10°C	>5 log reduction	TR-942	N/A
EN14349	<i>Escherichia coli</i>	1 min, Low soil, 10°C	>4 log reduction	TR-944	N/A
EN1656	<i>Streptococcus equi</i>	1 min, Low soil, 10°C	>5 log reduction	TR-931	N/A
EN14349	<i>Streptococcus equi</i>	1 min, Low soil, 10°C	>4 log reduction	TR-935	N/A
EN1656	<i>Campylobacter jejuni</i>	1 min, Low soil, 10°C	>5 log reduction	TR-931	N/A
EN14349	<i>Campylobacter jejuni</i>	1 min, Low soil, 10°C	>4 log reduction	TR-935	N/A
EN1656	<i>Pasteurella multocida</i>	1 min, Low soil, 10°C	>5 log reduction	TR-931	N/A
EN14349	<i>Pasteurella multocida</i>	2 min, Low soil, 10°C	>4 log reduction	TR-950	N/A
EN14349	<i>Pasteurella multocida</i>	1 min, Low soil, 20°C	>4 log reduction	TR-949	N/A
EN1656	<i>MRSA (Methicillin resistant Staphylococcus aureus)</i>	1 min, Low soil, 10°C	>5 log reduction	TR-932	N/A

PRODUCT DATA PACK (PDP)	PDP REF: PDP-B3015-ANIGENE V01	
NAME: ANIGENE Professional Surface Disinfectant Spray CODE: B3015		

EN14349	<i>MRSA (Methicillin resistant Staphylococcus aureus)</i>	1 min, Low soil, 10°C	>4 log reduction	TR-936	N/A
EN1656	<i>MRSE (Methicillin resistant Staphylococcus epidermidis)</i>	1 min, Low soil, 10°C	>5 log reduction	TR-932	N/A
EN14349	<i>MRSE (Methicillin resistant Staphylococcus epidermidis)</i>	1 min, Low soil, 10°C	>4 log reduction	TR-936	N/A
EN1656	<i>MRSP (Methicillin resistant Staphylococcus pseudintermedius)</i>	1 min, Low soil, 10°C	>5 log reduction	TR-932	N/A
EN14349	<i>MRSP (Methicillin resistant Staphylococcus pseudintermedius)</i>	1 min, Low soil, 10°C	>4 log reduction	TR-936	N/A
EN1656	<i>Salmonella typhimurium</i>	1 min, Low soil, 10°C	>5 log reduction	TR-933	N/A
EN14349	<i>Salmonella typhimurium</i>	1 min, Low soil, 10°C	>4 log reduction	TR-937	N/A
EN1656	<i>Brucella intermedia</i>	1 min, Low soil, 10°C	>5 log reduction	TR-933	N/A
EN14349	<i>Brucella intermedia</i>	1 min, Low soil, 10°C	>4 log reduction	TR-937	N/A
EN1656	<i>Bordetella bronchiseptica</i>	1 min, Low soil, 10°C	>5 log reduction	TR-933	N/A
EN14349	<i>Bordetella bronchiseptica</i>	1 min, Low soil, 10°C	>4 log reduction	TR-937	N/A
EN13623	<i>Legionella pneumophila</i>	1 min, 0.0005% yeast extract, 10°C	>5 log reduction	TR-899	N/A

YEASTICIDAL/FUNGICIDAL EFFICACY					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN1657	<i>Candida albicans</i>	1 min, Low soil, 10°C	>4 log reduction	TR-943	N/A
EN16438	<i>Candida albicans</i>	2 min, Low soil, 10°C	>3 log reduction	TR-948	N/A
EN16438	<i>Candida albicans</i>	1 min, Low soil, 20°C	>3 log reduction	TR-947	N/A
EN1657	<i>Aspergillus brasiliensis</i>	15 min, Low soil, 10°C	>4 log reduction	TR-900	N/A
EN16438	<i>Aspergillus brasiliensis</i>	15 min, Low soil, 10°C	>3 log reduction	TR-902	N/A
EN1657	<i>Trichophyton mentagrophytes</i>	5 min, Low soil, 10°C	>4 log reduction	TR-956	N/A
EN16438	<i>Trichophyton mentagrophytes</i>	10 min, Low soil, 10°C	>3 log reduction	TR-957	N/A

PRODUCT DATA PACK (PDP)	PDP REF: PDP-B3015-ANIGENE V01	
NAME: ANIGENE Professional Surface Disinfectant Spray CODE: B3015		

VIRUCIDAL EFFICACY					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN14675	Modified vaccinia Ankara	1 min, Low soil, 10°C	>4 log reduction	TR-938	All enveloped viruses (e.g. FIV, Feline coronavirus, influenza viruses)
EN14675	Bovine enterovirus (ECBO)	5 min, low soil, 10°C	>4 log reduction	TR-707	All non enveloped viruses (e.g. parvovirus, feline calicivirus)

VIRUCIDAL EFFICACY AGAINST BACTERIOPHAGES					
TEST REF	TEST ORGANISMS	TEST CONDITIONS	TEST RESULT	REPORT REF	COMMENTS
EN13610	Lactococcus lactis subsp. lactis P001 DSM 4262	5 min, 1% acidic whey, 20°C	>4 log reduction	TR-692	N/A
EN13610	Lactococcus lactis subsp. lactis P008 DSM 10567	5 min, 1% acidic whey, 20°C	>4 log reduction	TR-692	N/A

ADDITIONAL DATA		
TEST METHOD	RESULT	TEST REPORT REF
Preservative Efficacy Testing	B3015 complies with the test for the Efficacy of Antimicrobial Preservatives (European Pharmacopoeia 11th Edition)	TRC_334
Material Compatibility Testing	Compatible with surfaces such as stainless steel, mild steel, copper, nylon, acetal, rubber and aluminium.	TRC_322
Hard Surface Cleaning Test	B3015 is effective at cleaning both synthetic vomit and blood stains from polyurethane substrate (substitute for hard flooring)	TRC_326

CHANGE HISTORY			
VERSION	CHANGE REFERENCE	CHANGE TYPE	REASON FOR CHANGE
01	DCC24.129	NEW	New product Data Pack for new product

PDP-B3015-ANIGENE v01

Final Audit Report

2024-10-01

Created:	2024-10-01
By:	Megan Bowles (mbowles@byotrol.com)
Status:	Signed
Transaction ID:	CBJCHBCAABAAT_LTRx_z9sBTgkRmJG-1JsfbCSeBUfa0

"PDP-B3015-ANIGENE v01" History

-  Document created by Megan Bowles (mbowles@byotrol.com)
2024-10-01 - 9:14:40 AM GMT
-  Document emailed to mhunt@byotrol.com for signature
2024-10-01 - 9:14:44 AM GMT
-  Email viewed by mhunt@byotrol.com
2024-10-01 - 9:15:11 AM GMT
-  Signer mhunt@byotrol.com entered name at signing as Matthew Hunt
2024-10-01 - 9:15:31 AM GMT
-  Document e-signed by Matthew Hunt (mhunt@byotrol.com)
Signature Date: 2024-10-01 - 9:15:33 AM GMT - Time Source: server
-  Document emailed to cplummer@byotrol.com for signature
2024-10-01 - 9:15:34 AM GMT
-  Email viewed by cplummer@byotrol.com
2024-10-01 - 10:49:35 AM GMT
-  Signer cplummer@byotrol.com entered name at signing as C. Plummer
2024-10-01 - 10:52:44 AM GMT
-  Document e-signed by C. Plummer (cplummer@byotrol.com)
Signature Date: 2024-10-01 - 10:52:46 AM GMT - Time Source: server
-  Document emailed to Megan Bowles (mbowles@byotrol.com) for approval
2024-10-01 - 10:52:47 AM GMT
-  Email viewed by Megan Bowles (mbowles@byotrol.com)
2024-10-01 - 10:54:39 AM GMT

 Document approved by Megan Bowles (mbowles@byotrol.com)

Approval Date: 2024-10-01 - 10:54:56 AM GMT - Time Source: server

 Agreement completed.

2024-10-01 - 10:54:56 AM GMT