



Recommended daily protocols for Veterinary Clinics

Category	Product	Strength	Preparation	Contact Time
Consultation Room	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	5 minutes Leave to air dry.
Prep Room	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	5 minutes Leave to air dry.
Kennel / Cattery	ANIGENE Professional Surface Disinfectant Cleaner	2%	Dilute 20ml of ANIGENE into 980ml water	30 minutes Rinse feeding equipment and toys.
Theatre	ANIGENE Professional Surface Disinfectant Cleaner	2%	Dilute 20ml of ANIGENE into 980ml water	Leave to air dry.
Isolation	ANIGENE Professional Chlorine Disinfectant Tablets	5000ppm	Dissolve 5 tablets into 1 litre of warm water	15 minutes Rinse all surfaces after use.
Staff Areas / Offices	ANIGENE Professional Surface Disinfectant Cleaner	2%	Dilute 20ml of ANIGENE into 980ml water	30 minutes Leave to air dry. Rinse food contact surfaces.
Reception	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	Leave to air dry.

Byotrol Technology Ltd
Building 303, Thornton Science Park, Pool Lane,
Ince, Chester, CH2 4NU, UK

©Byotrol 2024, all rights reserved. ANIGENE, Byotrol and the Byotrol logos are trademarks of Byotrol Ltd.
ANIGENEVET-LVC01

byotrol.com/resources





Recommended deep clean protocols for Veterinary Clinics (minimum monthly)

Category	Product	Strength	Preparation	Contact Time
Consultation Room	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	5 minutes Leave to air dry.
Prep Room	ANIGENE Professional Chlorine Disinfectant Tablets	5000ppm	Dissolve 5 tablets into 1 litre of warm water	15 minutes Rinse all surfaces after use.
Kennel / Cattery	ANIGENE Professional Chlorine Disinfectant Tablets	5000ppm	Dissolve 5 tablets into 1 litre of warm water	15 minutes Rinse all surfaces after use.
Theatre	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	Leave to air dry.
Isolation	ANIGENE Professional Chlorine Disinfectant Tablets	5000ppm	Dissolve 5 tablets into 1 litre of warm water	15 minutes Rinse all surfaces after use.
Staff Areas / Offices	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	Leave to air dry.
Reception	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	Leave to air dry.

Byotrol Technology Ltd
Building 303, Thornton Science Park, Pool Lane,
Ince, Chester, CH2 4NU, UK

©Byotrol 2024, all rights reserved. ANIGENE, Byotrol and the Byotrol logos are trademarks of Byotrol Ltd.
ANIGENEVET-LVC01

byotrol.com/resources





Disease management in Veterinary Clinics

Category	Product	Strength	Preparation	Contact Time
Parvo virus	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	5 minutes Leave surface to air dry.
Giardia	ANIGENE Professional Chlorine Disinfectant Tablets	5000ppm	Dissolve 5 tablets into 1 litre of warm water	15 minutes Rinse all surfaces before and after use.
Ringworm	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	15 minutes Leave surface to air dry.
Kennel Cough	ANIGENE Professional Surface Disinfectant Cleaner	1%	Dilute 10ml of ANIGENE into 990ml water	5 minutes Leave surface to air dry.
Leptospirosis	ANIGENE Professional Surface Disinfectant Cleaner	1%	Dilute 10ml of ANIGENE into 990ml water	5 minutes Leave surface to air dry.
Cat Flu	ANIGENE Professional Surface Disinfectant Cleaner	10%	Dilute 100ml of ANIGENE into 900ml water	15 minutes Leave surface to air dry.

Byotrol Technology Ltd
Building 303, Thornton Science Park, Pool Lane,
Ince, Chester, CH2 4NU, UK

©Byotrol 2024, all rights reserved. ANIGENE, Byotrol and the Byotrol logos are trademarks of Byotrol Ltd.
ANIGENEVET-LVC01

byotrol.com/resources

